

STARTUP GUIDE

For proper use of the Hybrid Mist, please read the Quick Guide before operation.

1: Insert power plug into outlet.

2: Turn fireplace on using the **On** button.

3: Fill Demineralised Water - monitor **Tank indicator** to avoid overfilling.

Use ONLY Demineralised Water to ensure fireplace warranty.

4: Start the fireplace using the **Start button** (you will hear the pump start).

After pressing the **Start button**, it will take approximately 2 minutes for steam to emit.

5: Stop the fireplace by pressing the **Stop button** and wait for the pump to stop (approximately 2 minutes). Only then, turn off the fireplace using the **Off button**.

6: If the fireplace suddenly stops producing steam, it is recommended to follow step 5 and wait approximately 15 minutes before restarting the fireplace.

If you have any questions, please contact us at info@decoflame.dk or call +45 9630 4800.

Kind Regards

Technical Department, DecoFlame ApS



Video:
Refilling and Draining the Fireplace

