

MONTREAL™ WITH HYBRID MIST

720MM / 920MM / 1120MM



The Hybrid Mist Fireplace in the Montreal casing offers a blend of modern design and innovative technology. It uses advanced atomisation to create a fine mist, which, when illuminated by integrated LED lights, simulates real flames.


A key advantage is safety; without real fire, it's ideal for homes with small children or pets, reducing burn or fire hazards. The absence of combustion also means no emissions, contributing to better indoor air quality.

The Montreal casing adds elegance and sophistication, fitting both contemporary and traditional interiors. It is easy to install and maintain, providing a hassle-free user experience. The mist and lighting effects are electronically controllable, allowing customisable ambiance for any occasion.


Montreal can also be ordered with the following burners:

- A. Denver F3 Burner
- B. Denver F6 Burner
- C. Manual Burner


Montreal Casing and Glass Solutions:




A: Open to front




B: Open to front and back



C: Open to front and right or left side



D: Open to front, back and right or left side



E: Open to front, right and left side

Decoflame strongly recommends installing glass shields in order to protect the Hybrid Mist from draught, while keeping it vivid.

Model A comes with one low glass or a full glassdoor.

Model B comes with two low glasses, one full glass and one low glass - or one full glass and one glassdoor.


Model C comes with two low glasses.

Model D comes with three low glasses or 2 full glasses and one glassdoor.

Model E comes with three low glasses.


We recommend it as mentioned for the best result regarding design and operation.

HYBRID MIST BURNER



Power supply: 220V - 240V, 50 Hz

INSTALLATION



Step 1: Make sure that the dimensions of the cut-out correspond to the measurements indicated in the technical drawing received with your fireplace. *Everything must be in level.*

Step 2: Connect the fireplace to an electrical power supply.

Step 3: Recess the fireplace into the wall cut-out according to the indications in the User's Manual.

Step 4: Place the glass screen/s on to the top pin holders.

Step 5: Turn on the fireplace. Fill in the right amount of Demineralized water by verifying the level on the indicator.

Step 6: Start the fireplace by pressing the Play/Start button on the control panel. Wait around 3 minutes before the fireplace is fully operational.

Only demineralised water may be used. If any other type is used, the warranty for the fireplace will be void.

Features

- Hybrid Mist Technology
- Water Level Indicator
- Flame Level Indicator
- Remote Control
- Bluetooth / App
- 6 Flame Levels

Optional

- Made to measure
- Brushed and brushed stainless steel
- RAL colours

Standard finishes



Optional

